



www.PRPSSeats.com

800.317.6253

fax 951.894.5108
41537 Cherry St, Murrieta, CA 92592

97-02 Jeep TJ Mounts

1. Remove your stock seats using the four bolts that connect your seats to the stock sliders.



2. Once the seats are removed you will need to remove the bolt that connects your seatbelt to the stock bracket.
 - Add two washers between the bolt head and the rubber washer.
 - Re-install the seat belt bolt into stock bracket. The washers are added to space the bolt down and give clearance for the PRP adaptors.

3. **(Step 3 is Passenger Side Only)** On the outside of the passenger side slider there are two brackets that are used for the original seat flip cable. These brackets will need to be removed to make room for the PRP adaptors.



- Remove the cable, if it was not already removed in step 1.
- Using a chisel or grinder remove the rivet and unscrew the bolt and spring holding on the two flip cable brackets.

4. Place a washer over the inside rear stud on both the passenger and driver side mounts.
5. Place the PRP adaptors onto the studs. The wide adaptor should be on the inside with the angle pointing up. Using the original bolts tighten the PRP adaptors.
6. Attach the spring, that was on the stock seat, to the back cross member of the stock bracket.
7. Install your new PRP seats. In order to center your seat you will need to place the seat tabs on the inside of the outside adaptor and outside of the inside adaptor. Then use four 3/8" bolts and nuts to secure your seat to the adaptors.

Use:

In order to flip your seat forward you will have to reach under the front of your seat to reach the flip handle. Since your new PRP seats do not fold you will have to slide

the forward before using the flip handle to make room for the person getting into the back seat.

