

# Install Instructions

## PRP Seats

### Can-Am Commander

### Front Door-Bag Installation



**Read through all of the instructions completely before beginning the install.**



#### **Parts Included:**

##### **A. Door Bags**

- 1 x Can-Am Commander Door Bag (Right)
- 1 x Can-Am Commander Door Bag (Left)

##### **B. Hardware**

- 18 x 3/16 Push Pins
- 1 x K-TEX Drill Hole Template

**Remove all parts from the bags and lay out the pieces.**

#### **Tools Needed:** (not included)

- 5/32" Drill Bit (3/16" also works)
- Drill
- Masking Tape

#### **Time:**

Approx 30 Minutes.



**1. Remove K-Tex Drill Hole Template from the bag.**

Place it up on the door, and tape it into place so it matches up with the curves in the door.

This same template will be used on the driver and passenger side.



**2. Use a 5/32" drill bit to create holes in the door plastic that the push pins will go into.**

\*Only go into the door about 1/4" depth (or until you feel it pop through the inner door plastic). Do not over drill or you will create a hole in the front of the door skin.

\*If you dont have an exact 5/32" bit, you can use a 3/16".



**3. Note:**

If you feel the drill having a lot of resistance, you most likely are drilling into one of the ridges on the back of the door.

If that happens - Stop, re-adjust the template, and drill again.



**4. Remove the Foam Cushion**

Unzip the front of the door bag, and remove the foam piece. Then slip the front of the bag through the handle, and into place on the door.



## 5. Install all the Push Pins

Place each pin into the bag through the hole, and into the door. Set the pin base into the door first, then push hard on the top pin to lock it into place.

There are push pin holes in the front & rear compartments, and underneath the door handle section.



## 6. Reinstall the Foam Piece into the bag

Stuff it back in, and close up the zipper.



## 7. And you're all set!

If you have any questions or experience issues, please contact your retail outlet first for assistance. However, the staff at PRP is always happy to help at **1-800-317-6253**, or email **customerservice@prpseats.com**

**Thank you! Ride Safe!**