

# Install Instructions

## PRP Seats Honda Talon 4 Rear Seat Install Instructions



Read through all of the instructions completely before beginning the install.

A.



### Parts Included:

A. 4 x Seat Adapters (Driver and Passenger)

B. Hardware

4 x 5/16" x 18 x 1" Bolts

4 x 5/16" USS Washers

4 x 5/16" Lock Washers

### Tools Needed: (not included)

12mm Socket

6mm Allen Wrench

1/2" Wrench (preferably with ratchet end)

B.



### Time:

Approx 45 Minutes.



### 1. Start by Removing the Stock Seats from the Vehicle.

Pull the release lever under the front of the seat, and remove the bottom cushion. Use a 6mm Allen Wrench to remove both bolts in the front of the seat. Then use a 12mm socket to remove both nuts in the rear of the seat. Then take the stock seat completely out.



### 2. Place the Adapter Mounts into the Vehicle.

These are right and left side specific. On each bracket there is a slot on top for the seats to slide into, that should be at the back.

Reinstall the Allen head bolts in the front, and nuts in the back - but only get them hand tight. (You will need to be able to slide the mounts side to side).



### 3. Adjust the Mount Width for the PRP Seat

Place the PRP Seat into the vehicle. Line up the feet in the back of the seat, with the slots on the mounts, and then slide them in.

You can now adjust the seat and mounts so that the bolt holes in the seat frame line up with the mounts. You also want to make sure it doesn't hit or rub against the center console.



### 4. Completely Tighten Down the Mounts

Once you have the seat width mounted correctly, use a 6mm Allen to tighten down the front two bolts. Then remove the seat (carefully so you don't move the mounts out of position). Then completely tighten down the rear nuts using a 12mm socket.

\*If you are going to install aftermarket harnesses, now is the time to get the lap belts bolted in.



## 5. Install the Seat into the Vehicle

Place the seat back into the vehicle, and slide the rear feet into the mounts. Place the supplied 5/16" x 18 x 1" Bolts, Lock & Flat Washers under the seat, and thread it into the hole with the mounts. Use a 1/2" Wrench (preferably with a ratchet end) to tighten down both bolts.

## 6. \*Note - Seat Height

With PRP Seats you gain about a 1/2" of extra headroom versus the stock seats. But you will have slightly less legroom. Full size adults can fit, but it will be more comfortable for young adults.



## 7. ... And You're All Done!

If you have any questions or experience issues, please contact your retail outlet first for help. However, the staff at PRP Seats is always happy to assist you.

1-800-317-6253.

[customerservice@prpseats.com](mailto:customerservice@prpseats.com)

Thank you! Ride safe!