

Teryx4 Rear Bench (A3652)

Install Instructions





Read through all of the instructions completely before beginning the install.

Parts Included:

- 1, 52" wide rear bench with 3 hoop headrests
- 2, Mounts for Teryx4 rear bench (Driver/Passenger)

Hardware Required:

- 2, 3/8" x 1" bolts
- 2, 3/8" x 3" bolts
- 8, Washers
- 4, Locking nuts

Tools required:

Phillips head screwdriver Ratchet and open end wrenches

Remove all parts from the box and unwrap completely using the packaging to lay out the pieces.

Time:

Approx 30 minutes.





- Remove the rear bucket seats and belts. Retain the bucket seat frame bolts for later.
- 2. Remove the Phillips head screws holding the black plastic piece, this is the large plastic part under the bucket seats. The rear cup holders are part of this piece.
- 3. Remove the plastic piece and cut the plastic as shown in picture A to within 1.5" of the floor and rear wall.
- 4. Reinstall the plastic base.
- 5. Thread the harnesses through the lap belt and shoulder harness slots in the bench seat.
- 6. Flip the bench seat over and install the lap belts to the mounts on the brackets that flare out.
- 7. Install the seat mounts to the seat, tighten the rear bolts until they are snug but not tight and the mounts pivot, tighten the front bolts finger tight
- 8. Install the seat, harness, mount assembly into the Teryx 4, use 3 people for best results
- 9. Remove the forward mounting bolts and lift the front of the seat. The seat will pivot up on the rear bolts and allow room to work underneath.
- 10. Align the seat mount slots with the original bucket seat mounting holes in the Teryx 4 chassis,
 - (Each Teryx 4 may be slightly different, it may be necessary to loosen the rear bolts a little to adjust the alignment)
- 11. Use the original bucket seat frame bolts with supplied washers to bolt the seat mounts to the Teryx 4 chassis
- 12. Tighten the rear bolts holding the seat mounts to the seat
- 13. Push the front of the seat down and align front bolt holes
- 14. Install front bolts and tighten
- 15. Install shoulder harness straps to the rear Tery 4 cage cross bars. Be sure to follow the instructions provided with the harnesses carefully using the proper wrap around technique.

